

# Connection Method of Wrist Server Battery


## Step 1:

Remove the four screws by the screwdriver and tweezers.




## Step 2:

Open the rear cover and you can see a lithium battery with a jack.



## Step 3:

Connect the battery wire to the power interface on the motherboard.



## Step 4:

Fit on the rear cover.

